



Important

Solar Type B-Lite Instructions

Lights must be charged prior to use.

When new, or in storage, the battery voltage may be insufficient for the light to operate properly.

The light should be charged in the off position for one day prior to use. The switch is located on the white back cover of the lens.